



UV
DISINFECTION

LOW PRESSURE
HIGH OUTPUT

DRINKING WATER


PROCESS WATER

← Applications

- Drinking water
- Process water
- Aquaculture
- Deozoneation
- TOC Reduction
- Ballast water
- Cooling tower
- Advanced oxidation

← Main characteristics

- Low Pressure High Output Amalgam Lamp
- "L" design reactor (in-line water inlet)
- Calibrated UV sensor
- Temperature sensor: reactor and panel
- Simple control logic



The Aquaray® SLP-DW (Drinking Water) and SLP-PW (Process Water) UV systems offer compact and high efficiency disinfection for small and medium application with a range of flowrates from 115 to 2645 gpm with exceptional reliability and ease of operation.

MAIN FEATURES

- High efficiency reactor with in-line water inlet
- Designed under DVGW Standard
- Exceptional lamp life of 16,000 h
- User friendly operator interface microprocessor controlled
- Easy to install in new or existing water plants
- Automatic wiper system (optional)
- Reactor mounting horizontal or vertical

UV TECHNOLOGY: SLP

The Aquaray® SLP units have been designed to disinfect potable or process water. The germicidal effect of the UV light inactivates most micro-organisms such as bacteria, viruses and parasites. UV is known to be particularly efficient to inactivate *Cryptosporidium Parvum* and *Giardia Lambli*a.

The UV dose (UV Intensity x contact time) defines the treatment efficiency which is provided by the unit. The effective dose applied depends on the UV transmittance of water to be treated as well as the proper hydraulic design of the unit.

HOW IT WORKS

The low pressure amalgam lamps are powered by electronic ballasts. The lamps are inserted in pure quartz sleeves isolating them from the water. The lamps can be easily changed when necessary. The micro-processor control unit indicates lamp operating hours and notifies the operator when the usable life (16,000 h) is reached.

A UV sensor is installed to monitor UV radiation. The periodic maintenance of the system has been made very easy by allowing the removal of the full lamp assembly.

TECHNICAL DATA

Aquaray® SLP Model	Flow Rate ⁽¹⁾	Total Lamp Power
	gpm	W
SLP 150-75-1	115	200
SLP 200-100-2	265	400
SLP 200-150-3	395	600
SLP 250-150-4	615	800
SLP 250-200-6	880	1200
SLP 300-200-8	1280	1600
SLP 350-250-10	1675	2000
SLP 350-250-12	2025	2400
SLP 400-300-14	2645	2800

(1) Based on 40 mJ/cm² UV dose at 95% UV transmittance


► Materials

- **Reactor Material:** 316L stainless steel/quartz sleeve/
silicon O-ring
- **Panel Material:** mild steel polyester powder coated

DIMENSIONS

Aquaray® SLP Model	Reactor (inch)													In-Out	Panel: l x h x w (inch)
	A	B	C	D	E	F	G	H	J	K	L	M	N	inch	
SLP 150-75-1	6	49	6	6	9	9	7	39	5	6	5	12	54	3	16 x 24 x 8
SLP 200-100-2	8	49	6	7	11	9	7	39	7	8	6	12	54	4	16 x 24 x 8
SLP 200-150-3	8	49	6	7	11	9	7	39	7	8	6	12	54	6	24 x 24 x 8
SLP 250-150-4	10	53	6	8	13	13	7	39	9	10	7	12	54	6	24 x 24 x 8
SLP 250-200-6	10	53	6	8	13	13	7	39	9	10	7	12	54	8	24 x 24 x 8
SLP 300-200-8	12	52	7	10	15	13	7	39	11	12	8	12	54	8	32 x 32 x 8
SLP 350-250-10	14	51	8	12	17	13	7	39	13	14	10	12	54	10	32 x 32 x 8
SLP 350-250-12	14	51	8	12	17	13	7	39	13	14	10	12	54	10	32 x 32 x 8
SLP 400-300-14	16	51	8	12	19	13	7	39	15	16	10	12	54	12	32 x 32 x 8

Size connection flanges confirmed with proposal



Contacts

WWW.DEGREMONT-TECHNOLOGIES.COM

Ozonía North America

Ozonía International UV

Ozonía France

Ozonía Switzerland

Ozonía Triogen UK

Ozonía Russia OOO

Ozonía Korea

Ozonía China

Ozonía Japan

• info-ozonia@degtec.com

• info-ozoniaFR@degtec.com

• info-ozoniaFR@degtec.com

• info-ozoniaCH@degtec.com

• info-triogen@degtec.com

• info-ozoniaRU@degtec.com

• info-ozoniaKR@degtec.com

• info-china@degtec.com

• info-japan@degtec.com

• + 1 201 676 2525

• + 33 1 58 81 50 00

• + 33 1 58 81 50 00

• + 41 44 801 8511

• + 44 13 55 220 598

• + 7 831 434 1628

• + 82 31 701 9036

• + 86 10 659 73 860

• + 81 3 544 46 361

Manufacturers' Representative: